




## User manual



# User Manual

English

## Introduction

### Purchase

Congratulations on the purchase of a new Rotating Laser from Agatec.



### Product

This manual contains important safety directions as well as instructions for setting up the product and operating it. Refer to "Safety Directions" for further information.

Read carefully through the User Manual before you switch on the product.

### Symbols

The symbols used in this manual have the following meanings:



#### **DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



#### **WARNING**

Indicates a potentially hazardous situation or an unintended use which, if not avoided, could result in death or serious injury.



#### **CAUTION**

Indicates a potentially hazardous situation or an unintended use which, if not avoided, may result in minor or moderate injury and / or appreciable material, financial and environmental damage.

# Contents

<b>Introduction</b> .....	2
Features.....	4
Laser Overview {A} .....	4
Keypad Overview {B} .....	4
<b>Basic Operation</b> .....	6
How to use your Agatec RL110G .....	6
Button Functions.....	6
Automatic / Manual modes .....	7
H.I. Alert mode.....	7
Rotation mode .....	8
Scanning mode .....	8
Wall Mount .....	8
Set-up manual slopes .....	9
<b>Accessories</b> .....	9
Remote Control .....	9
Receiver/Remote Control .....	10
Other accessories .....	10
<b>Batteries</b> .....	11
First charge.....	11
Low battery Indicator .....	11
<b>Check and Adjust</b> .....	11
Notes and Responsibilities .....	11
Checking level accuracy .....	11
Checking vertical accuracy .....	12
Adjusting level accuracy .....	12
<b>Troubleshooting</b> .....	13
<b>Care and Transport</b> .....	14
Transport.....	14
Storage .....	14
Cleaning and Drying .....	15
<b>Safety Directions</b> .....	15
General .....	15
Intended Use.....	15
Limits of Use .....	16
Responsibilities .....	16
Hazards of Use .....	17
Laser Classification .....	19
Electromagnetic Compatibility (EMC) .....	22
FCC Statement, Applicable in U.S. ....	22
<b>International Limited Warranty</b> .....	23
<b>Technical Data</b> .....	24

## Features

The Agatec RL110G laser offers the interior contractor many great features to make work easier and more accurate.

A complete laser, with all needed functions, a bright beam for high visibility, with very compact dimensions.

## Laser Overview {A}

See the inside front cover for a diagram of the laser {A} and keypad {B} corresponding to these callouts.


- 1) Rotating head
- 2) Axes indications
- 3) Plumb or square beam laser beam aperture
- 4) Rotating laser beam aperture
- 5) Batteries
- 6) 5/8"-11 Tripod mount for horizontal setup

## Keypad Overview {B}


The keypad for the Agatec RL110G laser has seven buttons and three LED indicators.

- 1) On / Off
- 2) H.I. (Elevation) Alert
- 3) UP
- 4) DOWN
- 5) Rotation Mode
- 6) Scan
- 7) Manual Mode
- 8) LED – H I indication
- 9) LED – Level Status / Battery
- 10) LED – Manual mode indication

## Laser Overview {A}



## Keypad Overview {B}



# How to use your Agatec RL110G

### Horizontal Setup

The laser can be mounted on a 5/8"-11 tripod or placed directly on a solid, stable surface. Agatec RL110G can be suspended from a ceiling grid using the wall mount.

### Vertical Setup

The laser can be placed directly on its back (opposite the handle) on a solid, stable surface. For more stability, it is recommended to use the wall mount.

### Turning on the laser

Turn on the laser with the On/Off key **{B-1}**. It does a self-test and the beam blinks while the laser is self-leveling. After it is leveled, the head rotates. You can choose H.I. Alert mode or change to manual mode (see later sections).

The laser has a wide self-leveling range; however, if the laser is set up out of the leveling range, the laser beam will continue to blink and the rotation will not start.

### LED indication

The LED indicator **{B-9}** slowly blinks green while the axes are leveling and stays on when both axis has reached a level position.

## Button Functions

The UP/DOWN buttons on the laser and the remote control buttons have multiple functions depending on the mode of operation. Please refer to the chart below to better understand their functionality.

Mode	UP / DOWN Laser buttons and remote buttons	RIGHT/LEFT Only Remote Buttons
Automatic mode - rotating	Switches to point mode	Cycle through the rotating speed
Automatic mode - scanning	Moves scan CW/CCW	Cycle through the scanning width
Laydown mode - rotating	Slope	Cycle through the rotating speed
Laydown mode - scanning	Slope	Cycle through the scanning width
Manual mode - rotating	Slope	Cycle through the rotating speed
Manual mode - scanning	Slope	Cycle through the scanning width

## Automatic / Manual modes

The Agatec RL110G is in automatic, self-leveling mode when turned on. Once the instrument has self-leveled, the laser head will start rotating with 300 rpm.

In manual mode, the laser does not self-level; this means that the beam will rotate even if the laser is not leveled. It can therefore be used on inclined planes such as stairs, roofs, or when manual grade setting is required. See later section on setting slope in manual or semi-automatic modes.

## H.I. Alert mode

The H.I. feature stops the laser automatically if the laser is disturbed, preventing inaccurate readings. It functions only when activated.

- To activate this safeguard feature, keep pressed the H.I. key **{B-2}** after turning on the laser. The H.I. LED **{B-8}** will blink rapidly while the laser is initializing the H.I. mode.

- Thirty seconds later, the LED will blink slowly, indicating the H.I. Alert function is activated.
- If the laser is disturbed while in H.I. Alert mode, the head will stop rotating, the beam will turn off, the LED indicator will be on continuously.
- Press the ON/Off key to turn off the H.I. Alert function. Press again the ON/OFF key to have the unit going back to the default settings (300 rpm, automatic mode).

## Rotation mode

The head rotates at three speeds: 0, 300, 450, 600 rpm. The default setting is 300 rpm. The laser beam is more visible at slower rotation speeds.

- To cycle through the rotation speeds press the key **{B-5}**. Press once to get to 450 rpm, twice to 600 rpm (max speed), three times to get to point mode. One more time to get back to 300 rpm.
  - When in point mode, the point can be moved to the right or left using the UP/DOWN keys **{B-3 and B-4}**. It is also possible to move the head manually to position the beam point.
- To start rotation again, press the key **{B-5}**.

## Scanning mode

For interior applications, scanning mode allows you to see the beam easier at a distance.

The default width has medium dimension. The laser beam is more visible at small width.

- To scan press the key **{B-6}**.
- To cycle through the scan width, press the key **{B-6}**. Press once to increase the width, twice to increase more. One more time to get to themimum width.
- The scanning beam can be moved to the right or left using the UP/DOWN keys **{B-3 and B-4}**.

## Wall Mount

For interior application, such as drywall installation, it is recommended to use the wall mount. Use the tripod thread to fix the mount to the laser.



## Set-up for manual slopes

The Agatec RL110G can be used to manually create slopes for special applications, stairways, sloped ceilings, etc.

For slopes up to 10%, set up the laser in horizontal mode and use the keypad or remote to set the slope following the instructions below.

In full manual mode, the unit will not self-level on both axis, meanwhile the head will continue to rotate. The plane of laser light can be tilted in either one or both planes.

### To use the laser in full manual mode:

- After turning the laser on and allowing it to self-level, press the Manual button **{B-7}**. The LED **{B-10}** indicates that the laser is in manual mode and you can set slope in the X-axis.
- Press UP/DOWN keys to adjust the slope of the X-axis.

Press the Manual key **{B-7}** once more to set slope on Y-axis. The LED **{B-10}** blinks to indicate that the laser is in manual mode and you can set slope in the Y-axis.


Keep pressed the MAN key to exit the manual mode and return to the automatic mode.

## Accessories

### Remote Control {C}

The Remote Control has five buttons.

- 1) LEFT
- 2) RIGHT
- 3) Scan / Rotation Mode
- 4) UP
- 5) DOWN



Please refer to the table in "Button Functions" to better understand their functionality.

- The red LED at the top of the remote will flash each time a button is pressed, indicating that the remote is transmitting to the laser.
- **Battery** - To open the battery compartment and change the battery, push the battery cover in the direction of the arrow. The remote control requires alkaline battery.

## Receiver/Remote Control

The **receiver/remote control** is a combination of receiver and laser remote control. With power turned OFF, the unit performs as a remote.

The **receiver/remote control** has six buttons; two of which have dual functions depending on whether the unit is being used as a receiver or as a remote.

- 1) Audio (Receiver), **LEFT** Scan-Stationary Beam / Manual Slope (Remote)
- 2) Bandwidth (Receiver), **RIGHT** Scan-Stationary Beam / Manual Slope (Remote)
- 3) Power – On/Off (Receiver)
- 4) Scan / Rotation Mode
- 5) **UP** – Head Speed / Scan Width
- 6) **DOWN** – Head Speed / Scan Width

The **receiver/remote control** can be used as a receiver and attached magnetically to the ceiling grid to be used in place of the ceiling grid target in poor visibility conditions.

## Other accessories

- Laser enhancing glasses improve the visibility of the laser beam in bright light conditions.
- The ceiling grid targets are used to view the beam on suspended ceiling applications. The target attaches magnetically to the grid.

## Batteries

### First charge

Your laser is equipped with rechargeable NiMH batteries. You must charge it for 8 hours before first using the laser.

### Low battery Indicator

When the battery power is low, the LED {B-9} will blink red during operation. Batteries have to be replaced as soon as possible. When battery is empty, the laser head will stop rotating and the low battery LED {B-9} will stay on.

## Check and Adjust

### Notes and Responsibilities

- It is the responsibility of the user to follow operating instructions and to periodically check the accuracy of the instrument and work as it progresses.
- The laser is adjusted to the defined accuracy specifications at the factory. It is recommended to check your laser for accuracy upon receipt and periodically thereafter to ensure accuracy is maintained. If your laser requires adjustment, contact the nearest authorized service center or adjust the laser using the following procedure.
- Do not enter this mode or attempt adjustment unless you plan to change the accuracy. Accuracy adjustment should only be performed by a qualified individual that understands basic adjustment principles.

### Checking level accuracy

To check the level accuracy of your laser, place the unit on a flat, level surface or tripod approximately 30 meters (100 ft.) from a wall.

- Align the X-axis so that it is square to the wall. Allow the laser to self-level completely (approximately one minute after the laser begins to rotate). Then mark the position of the beam (Position 1).
- Rotate the laser 180°, allow it to self level and mark the opposite side of the first axis (Position 2).

- Align the Y-axis by rotating the laser 90° so that this axis is now square to the wall. Allow the laser to self-level completely, and then mark the position of the beam (Position 3).
- Rotate the laser 180°, allow it to self level and mark the opposite side of the Y-axis (Position 4).
- The laser is within its accuracy specification if the four marks are within  $\pm 3$  mm ( $\pm 1/8$ " ) from the center.

## Checking vertical accuracy

To check the vertical accuracy of your laser, place the unit in the laydown position on a flat, level surface approximately 15-30 meters (50-100 ft.) from a wall.

- Hang a plumb line on the wall.
- Move the laser until the vertical, rotating beam is aligned to the plumb line.
- If the rotating beam is not plumb, adjustment is necessary.

## Adjusting level accuracy - the X, Y, Z axis

After checking the accuracy of your laser, perform the following steps to adjust the accuracy of the X-axis.

- Turn off the laser.
- Press and hold the H.I. key **{B-2}**, then press the ON/OFF key **{B-1}**.
- Release the H.I. key. After the three LEDs blink three times simultaneously.
  - The X-axis LED will flash rapidly (red) while leveling.
  - The X-axis LED will flash slowly (red) when ready for adjustment.
  - The head will not be rotating.
- Press a UP/DOWN Key **{C-4 or C-5}** to adjust the beam up or down. Five presses of the key will move the beam approximately 0.75 mm at 30 meters (1/32" at 100 feet).

After completing the changes to the X-axis, do one of the following steps:

- Press the Right key **{C-2}** after completing adjustment to switch to the Y-axis. Same process described above applies for the X-Axis.
- Press the ON/OFF key **{B-1}** at any time to turn off the laser without saving any changes.

To adjust the accuracy of the Z-axis, place the laser in the laydown position approximately 6 meters (20 feet) from a plumb line on a wall. Same adjusting process described above.

## Troubleshooting

Symptom	Possible Causes and Solutions
The laser beam blinks, but the unit will not self-level or rotate.	<p>The unit is most likely out of its 10% self-leveling range.</p> <ul style="list-style-type: none"><li>• Check your set up and re-level the tripod if necessary.</li><li>• If this does not solve the problem, the laser should be returned to an authorized service center for service.</li></ul>
The laser does not turn on.	<p>The symptom may be caused by low or dead batteries.</p> <ul style="list-style-type: none"><li>• Check or change the batteries.</li><li>• If not the batteries, the laser should be returned to an authorized service center for service.</li></ul>
The laser's distance is reduced.	<p>Dirt may be reducing the output of the laser.</p> <ul style="list-style-type: none"><li>• Clean the windows of the laser and receiver to improve distance.</li><li>• If not the windows, the laser should be returned to an authorized service center for service.</li></ul>
The IR Remote is not working.	<p>Check for proper operation of the remote.</p> <ul style="list-style-type: none"><li>• Check that the laser is turned on.</li><li>• The remote may be outside the usable distance.</li><li>• Aim the remote more directly at the laser for maximum distance.</li><li>• The remote's battery may be low.</li></ul>
The laser's receiver is not functioning properly.	<p>Check for proper operation of the receiver.</p> <ul style="list-style-type: none"><li>• The laser is not rotating. It is leveling or in elevation alert.</li><li>• The laser is in scanning mode.</li><li>• The receiver may be outside the usable distance.</li><li>• The receiver's battery may be low.</li></ul>
ALL three LED's are flashing in sequence.	<p>The unit has been moved or pushed as HI was active. Press ON/OFF to restart the unit.</p>

### Transport

#### Transport in the field

When transporting the equipment in the field, always make sure that you

- either carry the product in its original transport container,
- or carry the tripod with its legs splayed across your shoulder, keeping the attached product upright.

#### Transport in a road vehicle

Never carry the product loose in a road vehicle, as it can be affected by shock and vibration. Always carry the product in its transport container and secure it.

#### Shipping

When transporting the product by rail, air or sea, always use the complete original Agatec packaging, transport container and cardboard box, or its equivalent, to protect against shock and vibration.

#### Shipping, transport of batteries

When transporting or shipping batteries, the person in charge of the product must ensure that the applicable national and international rules and regulations are observed. Before transportation or shipping, contact your local passenger or freight transport company.

#### Field Adjustment

After transport inspect the field adjustment parameters given in this user manual before using the product.

### Storage

#### Product

Respect the temperature limits when storing the equipment, particularly in summer if the equipment is inside a vehicle. Refer to "Technical Data" for information about temperature limits.

#### Field Adjustment

After long periods of storage inspect the field adjustment parameters given in this user manual before using the product.

#### Alkaline Batteries

If the equipment is to be stored for a long time, remove the alkaline batteries from the product in order to avoid the danger of leakage.

## Cleaning and Drying

### Product and Accessories

- Blow dust off optical parts.
- Never touch the glass with your fingers.
- Use only a clean, soft, lint-free cloth for cleaning. If necessary, moisten the cloth with water or pure alcohol.
- Do not use other liquids; these may attack the polymer components.

### Damp Products

- Dry the product, the transport container, the foam inserts and the accessories at a temperature not greater than 40°C / 104°F and clean them.
- Do not repack until everything is completely dry.

## Safety Directions

### General

#### Description

The following directions should enable the person responsible for the product, and the person who actually uses the equipment, to anticipate and avoid operational hazards.

The person responsible for the product must ensure that all users understand these directions and adhere to them.

### Intended Use

#### Permitted Use

- The instrument casts a horizontal laser plane for the purposes of alignment.
- The unit can be set up on its own base plate, wall-mount or on a tripod.
- The laser beam can be detected by means of a laser detector.
- This product is intended for indoor use and applications.

## **Adverse Use**

- Use of the product without instruction.
- Use outside of the intended limits.
- Disabling safety systems.
- Removal of hazard notices.
- Opening the product using tools, for example screw- driver, unless this is specifically permitted for certain functions.
- Modification or conversion of the product.
- Use after misappropriation.
- Use of products with obviously recognizable damages or defects.
- Use with accessories from other manufacturers without the prior explicit approval of Agatec.
- Inadequate safeguards at the work site, for example when using on or near roads.
- Deliberate dazzling of third parties.
- Controlling of machines, moving objects or similar monitoring application without additional control and safety installations.

## **WARNING**

Adverse use can lead to injury, malfunction and damage. It is the task of the person responsible for the equipment to inform the user about hazards and how to counteract them. The product is not to be operated until the user has been instructed on how to work with it.

## **Limits of Use**

### **Environment**

Suitable for use in an atmosphere appropriate for permanent human habitation: not suitable for use in aggressive or explosive environments.

### **DANGER**

Local safety authorities and safety experts must be contacted before working in hazardous areas, or in close proximity to electrical installations or similar situations by the person in charge of the product.

## **Responsibilities**

### **Manufacturer of the product**

Agatec SAS, 60, route de Sartrouville, 78230 Le Pecq - France, hereinafter referred to as Agatec, is responsible for supplying the product, including the user manual and original accessories, in a completely safe condition.



### **Manufacturers of non Agatec accessories**

The manufacturers of non Agatec accessories for the product are responsible for developing, implementing and communicating safety concepts for their products, and are also responsible for the effectiveness of those safety concepts in combination with the Agatec product.

### **Person in charge of the product**

The person in charge of the product has the following duties

- To understand the safety instructions on the product and the instructions in the user manual.
- To be familiar with local regulations relating to safety and accident prevention.
- To inform Agatec immediately if the product and the application becomes unsafe.

### **WARNING**

The person responsible for the product must ensure that it is used in accordance with the instructions. This person is also accountable for the training and the deployment of personnel who use the product and for the safety of the equipment in use.

## **Hazards of Use**

### **WARNING**

The absence of instruction, or the inadequate imparting of instruction, can lead to incorrect or adverse use, and can give rise to accidents with far-reaching human, material, financial and environmental consequences.

#### **Precautions:**

All users must follow the safety directions given by the manufacturer and the directions of the person responsible for the product.

### **CAUTION**

Watch out for erroneous measurement results if the product has been dropped or has been misused, modified, stored for long periods or transported.

#### **Precautions:**

Periodically carry out test measurements and perform the field adjustments indicated in the user manual, particularly after the product has been subjected to abnormal use and before and after important measurements.



## **DANGER**

Because of the risk of electrocution, it is very dangerous to use grade rods and staffs in the vicinity of electrical

installations such as power cables or electrical railways.

### **Precautions:**

Keep at a safe distance from electrical installations. If it is essential to work in this environment, first contact the safety authorities responsible for the electrical installations and follow their instructions.

## **WARNING**

If the product is used with accessories, for example masts, staffs, poles, you may increase the risk of being struck by lightning.

### **Precautions:**

Do not use the product in a thunderstorm.

## **WARNING**

Inadequate securing of the working site can lead to dangerous situations, for example in traffic, on building sites, and at industrial installations.

### **Precautions:**

Always ensure that the working site is adequately secured. Adhere to the regulations governing safety and accident prevention and road traffic.

## **CAUTION**

If the accessories used with the product are not properly secured and the product is subjected to mechanical shock, for example blows or falling, the product may be damaged or people may sustain injury.

### **Precautions:**

When setting-up the product, make sure that the accessories are correctly adapted, fitted, secured, and locked in position. Avoid subjecting the product to mechanical stress.

## **CAUTION**

During the transport, shipping or disposal of batteries it is possible for inappropriate mechanical influences to constitute a fire hazard.

### **Precautions:**

Before shipping the product or disposing of it, discharge the batteries by running the product until they are flat. When transporting or shipping batteries, the person in charge of the product must ensure that the applicable national and international rules and regulations are observed. Before transportation or shipping contact your local passenger or freight transport company.

## **WARNING**

High mechanical stress, high ambient temperatures or immersion into fluids can cause leakage, fire or explosions of the batteries.

**Precautions:**

Protect the batteries from mechanical influences and high ambient temperatures. Do not drop or immerse batteries into fluids.

**WARNING**

Short circuited battery terminals can overheat and cause injury or fire, for example by storing or transporting in pockets if battery terminals come in contact with jewellery, keys, metallized paper or other metals.

**Precautions:**

Make sure that the battery terminals do not come into contact with metallic objects.

**CAUTION**

During the operation of the product there is a hazard of squeezing extremities by moving parts.

**Precautions:**

Keep extremities in a safe distance from the moving parts.

**WARNING**

If the product is improperly disposed of, the following can happen:

- If polymer parts are burnt, poisonous gases are produced which may impair health.
- If batteries are damaged or are heated strongly, they can explode and cause poisoning, burning, corrosion or environmental contamination.
- By disposing of the product irresponsibly you may enable unauthorized persons to use it in contravention of the regulations, exposing themselves and third parties to the risk of severe injury and rendering the environment liable to contamination.

**Precautions:**

The product must not be disposed with household waste. Dispose of the product appropriately in accordance with the national regulations in force in your country.

**WARNING**

Only Agatec authorized service workshops are entitled to repair these products.

## Laser Classification

**General**

The following directions (in accordance with the state of the art - international standard IEC 60825-1 (2007-03) and IEC TR 60825-14 (2004-02)) provide instruction and training information to the person responsible for the product and the person who actually uses the equipment, to anticipate and avoid operational hazards.

The person responsible for the product must ensure that all users understand these directions and adhere to them.

Products classified as laser class 1, class 2 and class 3R do not require

- laser safety officer involvement,
- protective clothes and eyewear,
- special warning signs in the laser working area if used and operated as defined in this user manual due to the low eye hazard level.

Products classified as laser class 2 or class 3R may cause dazzle, flash blindness and afterimages, particularly under low ambient light conditions.

### **Agatec RL110G**

The rotating laser produces a visible green laser beam which emerges from the rotating head.

The laser product with a stationary rotating head is classified as laser class 3R in accordance with:

- IEC 60825-1 (2007-03): "Safety of laser products"

### **Class 3R laser products:**

Direct intrabeam viewing may be hazardous (low level eye hazard), in particular for deliberate ocular exposure. The risk of injury for laser class 3R products is limited because of:

- a)** unintentional exposure would rarely reflect worst case conditions of (e.g.) beam alignment with the pupil, worst case accommodation.
- b)** inherent safety margin in the maximum permissible exposure to laser radiation (MPE)
- c)** natural aversion behaviour for exposure to bright light for the case of visible radiation.

<b>Description</b>	<b>Value</b>
Maximum radiant power	< 2.7 mW c.w.
Pulse duration (effective)	4.5, 2.2, 1.5, 1.1 ms
Pulse repetition frequency	0, 2.5, 5, 7.5, 10 rps
Wavelength	529 - 535 nm
Beam divergence	< 1.5 mrad
NOHD (Nominal Ocular Hazard Distance) at 0.25s	35 m / 115 ft
Scan angle	2 to 36°

## WARNING

From a safety perspective class 3R laser products should be treated as potentially hazardous.

### Precautions:

Prevent direct eye exposure to the beam. Do not direct the beam at other people.

## WARNING

Potential hazards are not only related to direct beams but also to reflected beams aimed at reflecting surfaces such as prisms, windows, mirrors, metallic surfaces etc.


### Precautions:

Do not aim at areas that are essentially reflective, such as mirror, or which could emit unwanted reflections.



## Labelling, Laser Class 3R



2



1



# Electromagnetic Compatibility (EMC)

## Description

The term Electromagnetic Compatibility is taken to mean the capability of the product to function smoothly in an environment where electromagnetic radiation and electrostatic discharges are present, and without causing electromagnetic disturbances to other equipment.

## WARNING

Electromagnetic radiation can cause disturbances in other equipment. Although the product meets the strict regulations and standards which are in force in this respect, Agatec cannot completely exclude the possibility that other equipment may be disturbed.

## CAUTION

There is a risk that disturbances may be caused in other equipment if the product is used in conjunction with accessories from other manufacturers, for example field computers, personal computers, two-way radios, non-standard cables or external batteries.

### Precautions:

Use only the equipment and accessories recommended by Agatec. When combined with the product, they meet the strict requirements stipulated by the guidelines and standards. When using computers and two-way radios, pay attention to the information about electromagnetic compatibility provided by the manufacturer.

## CAUTION

Disturbances caused by electromagnetic radiation can result in erroneous measurements.

Although the product meets the strict regulations and standards which in this respect, Agatec cannot completely exclude the possibility product may be disturbed by very intense electromagnetic radiation, near radio transmitters, two-way radios or diesel generators.

### Precautions:

Check the plausibility of results obtained under these conditions.

## FCC Statement, Applicable in U.S.

## WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **WARNING**

Changes or modifications not expressly approved by Agatec for compliance could void the user's authority to operate the equipment.

### **REMOTE CONTROL**

---

IR Remote range	up to 30 m (100 ft)
-----------------	---------------------

---

Batteries	one AA alkaline battery
-----------	-------------------------

---

### **REMOTE RECEIVER CONTROL**

---

Batteries	a 9-volt type alkaline battery
-----------	--------------------------------

---

### **AGATEC SAS**

60, route de Sartrouville, 78230 Le Pecq, France

Tel. +33 1 34 93 35 80 - info@agatec.com - www.agatec.com

## **International Limited Warranty**

This product is subject to the terms and conditions set out in the International Limited Warranty which you can download from the Agatec home page at [www.agatec.com](http://www.agatec.com) or collect from your Agatec distributor. The foregoing warranty is exclusive and is in lieu of all other warranties, terms or conditions, express or implied, either in fact or by operation of law, statutory or otherwise, including warranties, terms or conditions of merchantability, fitness for a particular purpose, satisfactory quality and non-infringement, all of which are expressly disclaimed.

## Technical Data

SPECIFICATIONS	Agatec RL110G
Operating Range Ø	up to 60 m (200 ft) w/out receiver up to 200m (656 ft) w/ receiver
Self-leveling Accuracy*	± 1 mm at 10 m (± 0.04" at 33 ft)
Automatic Leveling	Horizontal/Vertical
Self-leveling Range	± 10%; 6°
Rotation Speeds	0, 300, 450, 600 rpm
Scanning Angle	variable from 2° to 36°
Laser Diode Type	532nm Class 3R; <5mW
Dimensions (H x W x D)	156 mm x 154 mm x 197 mm (6.1" x 6.06" x 7.75")
Weight with Batteries	Approx 1.5 kg ( 3.3 lbs)
Batteries	Rechargeable NiMH, 5V / 1A
Battery life**	25 hours.
Operating temperature	-10°C to 40°C (14°F to +104°F)***
Storage temperature (w/o batteries)	-20°C to 60°C ( -4° F to 140°F)
Protection against water	IP54, dust-proof, splash-proof

\* Accuracy is defined at 25°C

\*\* Battery life is dependent upon environmental conditions

\*\*\* **In cold temperatures, warm-up may be required.**

If you are using the laser when temperatures are between -10° and 0° C (14°F and 32° F), the laser beam will be visible within 10 to 12 minutes, and will reach full power within 20 to 25 minutes.



AGATEC  
60, route de Sartrouville  
78230 Le Pecq - France  
Tel. +33 1 34 93 35 80  
Fax +33 1 34 93 35 89  
info@agatec.com  
www.agatec.com

AGATEC Construction Lasers  
2202 Redmond Rd.  
Jacksonville, AR 72076  
Phone: 800.643.9696  
Fax: 501.982.0880  
sales@agatec-na.com  
www.agatec-na.com

Your dealer