



TOMAHAWK

TG3000i
INVERTER GENERATOR


Operation Manual




CRANKCASE



CRANKSHAFT



CYLINDER




CRANKCASE			
No.	Part No.	Description	Quantity
1	1230.T48.001V.04.00	Dipstick Subassembly, Oil	1
2	5787.06025.00.01	Bolt	6
3	1010.T48.001V.00.00	Over Subassembly, Crankcase	1
4	2090.148.001V.00.00	Oil Alarm Block	1
5	3170.188.001V.00.00	Pin	2
6	5787.06012.00.01	Bolt	2
7	3040.T48.001V.00.00	Over Subassembly, Crankcase	1
8	1000.T48.001V.00.00	Crankcase Subassembly	1
9	2090.T48.001V.00.00	Crimping Board	1
10	3150.T48.001V.00.00	Oil Seal	1


CRANKSHAFT			
No.	Part No.	Description	Quantity
1	0210.148.001V.00.00	Ring Set, Oil	1
2	0200.148.001V.00.00	Piston	1
3	0230.148.001V.00.00	Clip,Piston Pin	2
4	0220.148.001V.00.00	Pin,Piston	1
5	0190.148.001V.00.00	Rod,Connecting	1
6	0185.T48.001V.00.00	Crankshaft Gasket	1
7	0180.T48.001V.00.00	Crankshaft Assy	1

CYLINDER			
No.	Part No.	Description	Quantity
1	5789.06020.00.01	Bolt	4
2	0001.148.001V.00.00	Cover Subassembly,Cylinder Head	1
3	3000.148.001V.00.00	Gasket,Cover Subassembly	1
4	5789.06050.00.03	Bolt	4
5	2160.148.R001V.00.00	Plug,Spark	1
6	7071.165.001V.00.00	Bolt	2
7	3100.148.001V.00.00	Gasket,Exhaust Outlet	1
8	0010.T48.0011.00.00	Cylinder Head	1
9	0900.06088.00.01	Bolt	2
10	3020.148.001V.00.00	Gasket,Cylinder Head	1
11	3170.188.001V.00.00	Pin	2
12	7061.148.001V.00.00	Limit Plate Gasket	1
13	3088.148.001V.00.00	Breathing Valve Limit Plate	1


ENGINE STARTER



ELECTRICAL COMPONENTS



CAMSHAFT COMPONENTS




ENGINE STARTER			
No.	Part No.	Description	Quantity
1	2269.T48.001V.00.00	Rear Shield Housing	1
2	5789.06020.00.01	Bolt	2
3	7344.T48.001V.00.00	Bolt	2
4	5231.T48.001V.00.00	Rubber Sleeve of Rear Shield	1
5	2000.T48.001V.00.03	Wind Deflector	1
6	0845.48020.00.01	Self Tapping Screw	6
7	7071.T48.001V.00.00	Stud Support Bolt	2
8	2000.148.001V.00.04	Pulling Plate	1
9	5787.06016.00.01	Bolt	3
10	2268.T48.001V.00.00	Front Shield Housing	1


ELECTRICAL COMPONENTS			
No.	Part No.	Description	Quantity
1	4000.469.003V.00.02	Camshaft Assy	1
2	5787.06035.00.01	Oil Baffle	2
3	4000.469.001V.00.01	Rods	1
4	6177.12000.05.01	Intake Valve	1
5	2030.T48.0020.63.00	Exhaust Valve	1
6	2020.T48.001V.00.00	Valve Spring	1
7	0070.06010.00.04	Valve-Spring Seat	2

CAMSHAFT COMPONENTS			
No.	Part No.	Description	Quantity
1	1040.148.002V.00.00	Camshaft Assy	1
2	0085.148.001V.00.00	Oil Baffle	1
3	0160.T48.0010.00.00	Rods	2
4	0020.148.001V.00.00	Intake Valve	1
5	0030.148.001V.00.00	Exhaust Valve	1
6	0040.148.001V.00.00	Valve Spring	2
7	0060.148.001V.00.00	Valve-Spring Seat	2
8	0100.148.001V.00.00	Valve Rocker	2
9	0101.148.001V.00.00	Valve Rocker Shaft	1
10	1030.148.001V.00.00	Tappet	2


CARBURETOR



IGNITER ASSEMBLY



MUFFLER PARTS




CARBURETOR			
No.	Part No.	Description	Quantity
1	2260.T48.C01V.00.00	Stepper motor cover	1
2	2370.148.001V.00.00	Exhaust pipe	1
3	3060.148.001V.00.00	Air inlet gasket	1
4	2300.148.001V.00.00	Carburetor heat shield	1
5	3080.148.001V.00.00	Carburetor insulation pad	1
6	2260.T48.C01V.00.00	Carburetor	1
7	3090.148.001V.00.00	Carburetor gasket	1
8	2280.148.001V.00.02	Intake hose	1
9	6177.06000.00.01	Locking nut with disc	2
10	4000.435.006V.00.00	Stepper motor	1
11	2360.458.R005V.00.00	Ribbon tubing clamp	1
12	2360.458.R004V.00.00	Ribbon tubing clamp	3
13	2330.464.C010.00.021	Tubing	1
14	2325.469.0010.00.00	Fuel filter	1
15	2332.467.006V.00.00	Silicone protective sleeve	1


IGNITER ASSEMBLY			
No.	Part No.	Description	Quantity
1	5789.06018.00.01	Bolt	2
2	1522.T48.002V.00.00	Ignition coil	1
3	5789.06012.00.01	Bolt	1
4	5789.06035.00.01	Bolt	1
5	5695.T48.001V.00.00	Igniter mounting bracket	1
6	1020.164.0011.00.00	Oil alarm	1
7	5787.06012.00.01	Bolt	3
8	2050.T48.002V.00.00	Trigger coil assembly	1

MUFFLER PARTS			
No.	Part No.	Description	Quantity
1	2400.T48.001V.00.00	Muffler	1
2	6177.06000.00.01	Locking nut with disc	2
3	5789.06012.00.01	Bolt	1

ENGINE




INVERTER




ENGINE			
No.	Part No.	Description	Quantity
1	BP00.073.001.06	Engine	1
2	3360.473.0020.00.00	Shock Pad	2
3	5789.06012.00.01	Bolt	2
4	6177.06000.00.01	Nut	6
5	3350.T48.001V.00.00	Shock Mount	1
6	3350.T48.002V.00.00	Shock Mount	1

INVERTER			
No.	Part No.	Description	Quantity
1	3340.469.0020.00.00	Base Plate	1
2	3350.469.002V.00.00	Shock Absorber Of Unit	2
3	3350.469.001V.00.00	Shock Absorber Of Unit	2
4	5789.06018.00.01	Bolt	4
5	5789.06012.00.01	Bolt	2
6	6178.05000.00.04	Nut	4
7	3145.469.001V.00.00	Nut	6
8	2470.469.001V.00.00	Inverter	1
9	3410.467.003V.00.00	Ground Wire	1




PANEL			
No.	Part No.	Description	Quantity
1	6655.469.0040.00.00	Panel Bed	1
2	3370.469.1120.00.99	Panel	1
3	0818.05016.00.07	Cross Recessed Pan Head Screw	8
4	0818.04014.00.01	Screw	1
5	2141.467.001V.A6.00	Three In One Switch Handle	1
6	2140.467.011V.00.00	Three In One Switch	1
7	2140.467.011V.00.03	Cable Assembly	1
8	2332.467.002V.00.00	Sheath	1
9	0819.04212.00.01	Cross Countersunk Head Tapping Screw	3
10	6950.468.0020.00.00	Control Harness	1
11	6854.487.002V.00.00	Voltage Regulating Rectifier	1
12	5787.05016.00.01	Bolt	1


CONTROL PANEL



MUFFLER SHIELD



LEFT COVER




CONTROL PANEL			
No.	Part No.	Description	Quantity
1	6655.469.0040.00.00	Panel Bed	1
2	3370.469.1120.00.99	Panel	1
3	0818.05016.00.07	Cross Recessed Pan Head Screw	8
4	0818.04014.00.01	Screw	1
5	2141.467.001V.A6.00	Three In One Switch Handle	1
6	2140.467.011V.00.00	Three In One Switch	1
7	2140.467.011V.00.03	Cable Assembly	1
8	2332.467.002V.00.00	Sheath	1
9	0819.04212.00.01	Cross Countersunk Head Tapping Screw	3
10	6950.468.0020.00.00	Control Harness	1
11	6854.487.002V.00.00	Voltage Regulating Rectifier	1
12	5787.05016.00.01	Bolt	1


MUFFLER SHIELD			
No.	Part No.	Description	Quantity
1	2420.469.002V.04.00	Muffler Shield	1
2	0818.05016.00.07	Screw	6
3	7824.469.001V.00.00	Muffler Sealant Sleeve	1
4	5598.467.001V.00.00	Plum Ring	4

LEFT COVER			
No.	Part No.	Description	Quantity
1	2000.T70.001V.04.03	Starting Handle	1
2	0818.05010.00.07	Screw	3
3	2186.T48.001V.00.00	Cover Plate	1
4	7866.469.0011.00.00	Handle Trim Panel	1
5	5596.469.003V.P4.00	Ornament Shell	1
6	4789.467.001V.00.00	Step Bolts	3
7	5522.467.002V.00.00	Sheath	3
8	0818.05016.00.07	Screw	2
9	2220.469.002V.04.00	Left Shell	1
10	6178.05000.00.04	Nut	3

RIGHT COVER



FUEL TANK COMPONENTS



RIGHT COVER			
No.	Part No.	Description	Quantity
1	2222.469.002V.04.00	Right Shell	1
2	0818.05016.00.07	Cross Recessed Pan Head Screw	2
3	6178.05000.00.04	Nut	3
4	6234.467.002V.00.00	Sheath	1
5	4259.469.001V.A6.00	Spark-Plug Outer Cover	1
6	4562.469.001V.00.00	Anti Loss Rubber Strip	1
7	5522.467.002V.00.00	Sheath	3
8	4789.467.001V.00.00	Step Bolts	3
9	5596.469.004V.A6.00	Right Exterior Cover	1
10	0818.05010.00.07	Screw	2
11	6345.469.001V.04.00	Knob Limit Card	1
12	0845.04012.00.01	Screw	1
13	7540.469.002V.A6.00	Oil Maintenance Cover	1
14	1560.469.001V.04.00	Knob	1

FUEL TANK COMPONENTS			
No.	Part No.	Description	Quantity
1	3200.469.C01V.00.00	Tank,Fuel	1
2	3200.467.001V.00.02	Fuel Filter	1
3	3200.469.001V.00.03	Sheath	1
4	3200.467.C05V.00.01	Tank Cap	1
5	7868.469.001V.00.00	Sheath	3
6	3208.P70.001V.00.00	Filt Tip	1
7	2360.458.R007V.00.00	Ferrule	1
8	2330.469.C010.00.22	Oil Tube	1
9	2332.467.006V.00.00	Sheath	1
10	2360.458.R003V.00.00	Ferrule	1



Power Your World

Tomahawk understands to keep a job-site running smoothly the proper equipment and spare parts are needed at the drop of a hat. With same day shipping and faster delivery times, count on Tomahawk to keep you powered throughout the day! With long lasting parts and engines, Tomahawk equipment will be the star of your fleet for years to come. Visit www.tomahawk-power.com to get started today!

TOMAHAWK

TOMAHAWK®, LLC
San Diego, CA

Sales Support
(866) 577-4476
sales@tomahawk-power.com

Equipment Support
(866) 577-4476
support@tomahawk-power.com

www.tomahawk-power.com



FACEBOOK
facebook.com/TomahawkPowerUSA

YOUTUBE
youtube.com/TomahawkPower

INSTAGRAM
[@tomahawkpower](https://instagram.com/tomahawkpower)